


Getting started with Logitech® Bedside Dock



床頭音響底座 Model/型號: S-A0001

for iPad, iPhone, iPod touch






# Contents

English.																				. 4
繁體中文																				. 1
한국어 .																				. 18

#### **Product features**



#### **Bedside Dock front**

- 1. Tune up
- 6. Volume up 2. Tune down 7. Volume down
- 3. Alarm set
- 8. Source selection

4. Time set

- 9. Snooze
- 5. Device dock
- 10. Display





#### **Bedside Dock display**

- 11. Alarm 1 & 2
- 14. Radio
- 12. Auxiliary input
- 15. Alarm beep
- 13. Device source (e.g., iPod, iPhone, iPod Touch, iPod Nano, or iPad)

#### Bedside Dock top

- 16. Power on/off
- 17. Display dimmer







- Bedside Dock rear
- 18. Power input
- 19. FM antenna
- 20. Auxiliary 3.5mm

#### Setup

1 Install the backup clock batteries



If AC power is interrupted or you turn off the Bedside Dock, the batteries provide up to three months of backup power to the clock and alarm. **2** Connect the power cable



Input: 9V = 2000mA

alarm beep.

**3** Set the clock and alarm
The clock and alarm receive power from
the AC power supply. When power is
interrupted, the clock and alarm continue
to run on the two AAA alkaline batteries.
The alarm has two separate settings and
a choice of alarm source. Wake up to
sound from a docked device, FM radio, or

Time set: Press the Time Set button to set the time. The hour digits flash on the display. Use the Tune + or Tune - buttons to specify the hour. Press the Time Set button again. The minute digits flash. Use the Tune + or Tune - buttons to enter the minutes. Press the Time Set button once more to save your entry. Follow this procedure anytime you need to reset the time.

Alarm set: Press and hold the Alarm button to set alarm 1. The alarm 1 icon appears on the display and the hour digits flash. Release the button. Use the Tune + or Tune - buttons to specify the hour. Press the Alarm button again. The minute digits flash. Use the Tune + or Tune - buttons to enter the minutes. Press the Alarm button again. The alarm source flashes. Use the Tune + or Tune - buttons to choose an alarm source (e.g., docked device, radio, or buzzer). Press the Alarm button once more to save your entry. To set alarm 2, press the Alarm button until the alarm 2 icon appears. Repeat the procedure for setting alarm 1.

**Note:** If a docked device is disconnected from the Bedside Dock and this device has been selected as the alarm source, the Bedside Dock uses the alarm beep as the alarm source.


Alarm activation cycle: After you have set alarms 1 and 2, pressing the Alarm button repeatedly cycles through the following alarm activation states:

Alarm button	Alarm 1 state	Alarm 2 state
First press	On	Off
Second press	Off	On
Third press	On	On
Fourth press	Off	Off


Alarm sound: When the alarm sounds, it runs for one minute, is silent for four minutes, and then sounds for one minute. This cycle repeats for 30 minutes. The alarm 1 or alarm 2 icon on the display flashes.

Alarm on/off: When the Alarm sounds, press the alarm button on the Bedside dock to turn off the alarm.


**Alarm snooze:** Press the Snooze button or any button, except Alarm, to snooze the alarm for 5 minutes.



**Display brightness:** Press the Dimmer button on top of the Bedside Dock to cycle through four levels of display brightness.




4 Connect an audio source



Connect an iPod, iPhone, iPod Touch, iPod Nano, or iPad to the Bedside Dock. Your device will charge while docked, provided you have connected the Bedside Dock to an AC power source.

**5** Connect an audio device to the 3.5mm auxiliary input\*



\*A 3.5 mm audio cable is not included.

#### 6 Play music

- 1. Press the Power button to turn on the Bedside Dock.
- Select a source using the Source button, which cycles through the available sources:
  - Docked device (e.g., iPod, iPhone, iPod Touch, iPod Nano, or iPad)
  - FM radio
  - Auxiliary (e.g., MP3 player, or another device, connected to the auxiliary 3.5 mm input on the back of the Bedside Dock)

#### 3. Play music:

- For a docked device or auxiliary source, select a song or music track on your device, and then press "play." (Refer to your device documentation for more information.)
- For the FM radio, select a radio station using the Tune + and Tune - buttons. (See Select an FM channel in this guide for more information.)
- **4.** Adjust the volume using the Volume + and Volume buttons.

# **7** Select an FM channel

The Bedside Dock offers both auto and manual FM tuning.

**Auto search:** With the FM radio selected as the audio source, press and hold either the Tune + or Tune - button to initiate auto search. The search stops when the first tunable station is found. Press and hold either the Tune + or Tune - button again to continue auto search.

Manual search: Press the Tune + or Tune - button to select the next/previous FM station.

#### **Troubleshooting**

#### The Bedside Dock does not power on

- Is the power cable connected to the power input on the back of the Bedside Dock?
- Is the power cord plugged into an AC outlet?
- Is the Bedside Dock powered on? Press the Power button on top of the unit to turn on the Bedside Dock.

#### No sound or distorted sound

- Did you fully insert the audio device onto the dock?
- Adjust the volume. Use the Volume + and Volume - buttons to adjust the sound. Also check the volume level with the source device.
- Check your source connection, including the auxiliary 3.5 mm input.
- Make sure you have selected the source you would like to play.
- If you are trying to play music from a device connected to the auxiliary 3.5 mm input, select it using the Source button.
- Test the Bedside Dock using an alternate device.

# My audio device is not charging while connected to the Bedside Dock


- Did you fully insert your audio device onto the dock?
- Is the AC power cable plugged into the Bedside Dock?
- If the battery in your audio device is fully discharged, you may need to perform a recovery charge using the original power adapter for your audio device. (Refer to the documentation that comes with your audio device for more information about performing a recovery charge.)

#### Poor FM reception

 Try placing the FM antenna in different locations or rotating the antenna to improve reception.

If you have more questions about your Logitech Bedside Dock, visit www.logitech.com/support.

#### 產品功能





- 1. 向上調整
- 2. 向下調整
- 3. 鬧鈴設定
- 4. 時間設定
- 5. 裝置底座

- 6. 音量增大
- 7. 音量減小
- 8. 音源選擇
- 9. 貪睡功能
- 10. 顯示螢幕

14. 廣播

15. 鬧鈴聲響



#### 床頭音響底座顯示螢幕

- 11. 鬧鈴 1和 2
- 12. 輔助輸入端子
- 13. 裝置來源

(例如:iPod、iPhone、iPod


Touch \ iPod Nano


或 iPad)

### 床頭音響底座上方

16. 電源開/關

17. 顯示螢幕調光器





床頭音響底座背面


18. 電源輸入

19. FM 天線

**20.** 輔助 3.5 mm 輸入端子


# 安裝

# 1 裝上備用時鐘電池



如果交流電源中斷,或是您關閉床頭音響底座的電源時,電池可提供時鐘與鬧鈴長達 3個月的備用電力。

# 2 連接電源線



電氣規格: 9V -- 2000mA

#### 3 設定時鐘和鬧鈴

時鐘和鬧鈴接受來自電源供應器的電力。 電源中斷時,時鐘和鬧鈴仍可透過兩個 AAA 鹼性電池供電繼續運作。

鬧鈴可以有兩種不同的設定,並且可以選擇您要的音源。您可以選擇是要在連接裝置、FM 廣播或鬧鈴的聲響中醒過來。

時間設定:按下「時間設定」按鈕設定時間。此時,顯示螢幕上的小時數字會閃爍。使用「向上調整」或「向下調整」按鈕指定小時數字。再次按下「時間設定」按鈕。此時,分鐘數字會閃爍。使用「向上調整」或「向下調整」按鈕輸入分鐘數字。再按一次「時間設定」按鈕儲存您的輸入。隨時需要重設時間時,只要依照上述程序即可完成設定。

注意:如果連接裝置與床頭音響底座中斷連接, 且該裝置已被選為鬧鈴音源時,床頭音響底座會 使用鬧鈴聲響做為音源。

開**鈴啟動循環**:當您完成鬧鈴1與鬧鈴2的 設定後,可重複地按下「鬧鈴」按鈕,循環 變更鬧鈴啟動狀態:


#### Logitech® Bedside Dock

鬧鈴按鈕	鬧鈴1狀態	鬧鈴 2 狀態
第一次按下	開	見
第二次按下	見	開
第三次按下	開	開
第四次按下	見り	閱


開鈴聲:鬧鈴響起時,會持續一分鐘,靜音四分鐘,然後再響一分鐘。這個循環會重複 30 分鐘。顯示螢幕上的鬧鈴 1 或鬧鈴 2 圖示會閃爍。

**鬧鈴開/關:**鬧鈴響起時,按下床頭音響底座上的鬧鈴按鈕即可關閉鬧鈴。

開**鈴貪睡功能**:按下「貪睡功能」按鈕或除 鬧鈴按鈕外的任何按鈕,可使用貪睡功能 將鬧鈴關閉 5 分鐘。



**顯示螢幕亮度:**按下床頭音響底座上方的 「調光器」按鈕,可循環變更四種顯示器 亮度。




#### 4連接音源裝置



將 iPod、iPhone、iPod Touch、iPod Nano 或 iPad 接到床頭音響底座。接上後,您的 裝置即會開始充電 (床頭音響底座必須已經 連接交流電源)。

# 5 將音源裝置接到 3.5mm 輔助輸入端子\*



\*包裝中不含 3.5 mm 音訊連接線。

#### 6播放音樂

- 1. 請按下電源按鈕,開啟床頭音響底座 電源。
- 2. 使用「音源」按鈕選取音源,此按鈕會 循環顯示可用音源:
  - 連接裝置(例如:iPod \ iPhone \ iPod
     Touch \ iPod Nano 或 iPad)
  - FM 廣播
  - 輔助裝置(例如: MP3 播放器,或是 連接到床頭音響底座背面 3.5 mm 輔助輸入端子的其他裝置)

#### 3. 播放音樂:

- 如果是連接裝置或輔助裝置,請選取 您裝置上的歌曲或音樂曲目,然後按 下「播放」(請參閱裝置說明文件,以 取得更多資訊)。
- 如果是 FM 廣播,請使用「向上調整」或「向下調整」按鈕選取廣播電台(請參閱此指南中的「選取 FM 頻道」,以取得更多資訊)。
- **4.** 使用「音量增大」與「音量減小」按鈕 調整音量。

#### 7 選取 FM 頻道

床頭音響底座提供自動與手動兩種 FM 調校功能。

自動搜尋:當您選取FM廣播做為音源之後,請按住「向上調整」或「向下調整」按鈕來啟動自動搜尋功能。搜尋作業會在找到第一個可調電台後即停止。再次按住「向上調整」或「向下調整」按鈕可繼續執行白動搜尋功能。

手動搜尋:按「向上調整」或「向下調整」按鈕,選取下一個/上一個 FM 廣播電台。

#### 疑難排解

#### 床頭音響底座電源未開啟

- 電源線是否連接到床頭音響底座後方的電源輸入?
- 電源線是否插入交流電源插座?
- 是否已開啟床頭音響底座電源?請按下 此裝置上方的電源按鈕,開啟床頭音響 底座電源。

#### 沒有聲音/聲音失真

- 您已將音訊裝置完全插入底座了嗎?
- 調整音量。使用「音量增大」與「音量減小」按鈕調整聲音。另請檢查音源裝置的音量大小。
- 檢查您的音源連接,包含 3.5 mm 輔助輸入端子。
- 請確定您已經選取了要想播放的音源。
- 如果您嘗試播放連接到 3.5 mm 輔助輸入 端子之裝置上的音樂,請使用「音源」 按鈕選取該裝置。
- 使用其他裝置來測試床頭音響底座。

#### 我的音訊裝置在連接到床頭音響底座後, 未進行充電


- 您已將音訊裝置完全插入底座了嗎?
- 您已將交流電源線插入床頭音響底座 了嗎?
- 如果您音訊裝置中的電池已經完全耗盡電力,則可能必須使用您音訊裝置的原始轉接器來進行恢復充電(請參閱您音訊裝置提供的文件,取得更多有關進行恢復充電的資訊)。

#### FM 訊號接收不良


嘗試以不同方向放置 FM 天線,或旋轉天線以改善接收品質。

如果您對您的羅技床頭音響底座有其他疑問,請瀏覽 www.logitech.com/support。

## 제품 기능







#### 베드사이드 스피커 독 전면

- 1. 튠 업 6. 볼륨 높이기
- 2. 튠 다운 7. 볼륨 줄이기
- 3. 알람 설정 8. 소스 선택
- 4. 시간 설정 9. 스누즈
- 5. 장치 독 10. 디스플레이

#### 베드사이드 스피커 독 디스플레이

- 11. 알람 1 및 2
  - 14. 라디오 15. 알람 신호음
- 12. 보조 입력 13. 장치 소스

(예: iPod, iPhone,

iPod Touch, iPod Nano 또는 iPad)

#### 베드사이드 스피커 독 상단

16. 전원 켜기/끄기

17. 디스플레이

밝기 조정


#### 베드사이드 스피커 독 후면

18. 전원 입력 19. FM 안테나 20. 보조 3.5mm

입력


#### 설치

#### 1 보조 시계 배터리 장착



AC전원이 차단되거나베드사이드스피커독을 끄는 경우 배터리가 시계와 알람에 최대 3개월의 보조 전원을 제공합니다.

# 2 전원 케이블 연결



정격입력: 9V = 2000mA

#### 3 시계 및 알람 설정

시계 및 알람은 AC 전원 공급 장치에서 전원이 공급됩니다. 전원이 차단된 경우 시계 및 알 람은 두 개의 AAA 알카라인 배터리로 유지 됩니다.

알람에는 두 가지 별도의 설정 및 알람 소스 선택 항목이 있습니다. 도킹된 장치, FM 라디 오, 또는 알람 신호음의 사운드로 잠을 깨워줍 니다.

시간 설정: 시간 설정 버튼을 눌러 시간을 설정합니다. 시간 숫자가 디스플레이에 깜빡입니다. 튠 + 또는 튠 - 버튼을 사용하여 시간을 지정합니다. 시간설정버튼을다시 누릅니다. 분 숫자가 깜빡입니다. 튠 + 또는 튠 - 버튼을 사용하여 분을 입력합니다. 시간 설정 버튼을 한 번 더 눌러 입력 내용을 저장합니다. 시간을 재설정하려면 언제든 이 절차를 수행합니다.

알람 설정: 알람 버튼을 누른 상태로 알람1을 설정합니다. 알람1아이콘이 디스플레이에 나타나고 시간 숫자가 깜빡입니다. 버튼을 놓습니다. 튠 + 또는 튠 - 버튼을 사용하여 시간을 지정합니다. 알람 버튼을 다시 누릅니다. 분숫자가 깜빡입니다. 튠 + 또는 튠 - 버튼을 사용하여 분을 입력합니다. 알람 버튼을 다시누릅니다. 알람소스가 깜빡입니다. 튠 + 또는 튠 - 버튼을 사용하여 알람소스를 선택합니다(예: 도킹된 장치, 라디오 또는 버저). 알람버튼을 한 번 더 눌러 입력 내용을 저장합니다. 알람2를 설정하려면 알람2 아이콘이 나타날 때까지 알람 버튼을 누릅니다. 알람1의 설정 절차를 반복합니다.

참고: 도킹된 장치가 베드사이드 스피커 독에서 분리되고 이 장치가 알람 소스로 선택되어 있는 경우 베드사이드 스피커 독은 알람 신호음을 알람 소스로 사용합니다.


알람 활성화 주기: 알람 1및 2를 설정한 후, 알 람 버튼을 누르면 다음 알람 활성화 상태로 반복적으로 순환됩니다.

알람 버튼	알람 1 상태	알람 2 상태
첫 번째 누르기	켜짐	꺼짐
두 번째 누르기	꺼짐	켜짐
세 번째 누르기	켜짐	켜짐
네 번째 누르기	꺼짐	꺼짐


알람 사운드: 알람이 울리면 1분 동안 지속되고, 4분 동안 음소거된 다음 1분 동안 울립니다. 30분 동안 이러한 주기가 반복됩니다. 디스플레이의 알람 1 또는 알람 2 아이콘이 깜빡입니다.

**알람 켜기/끄기:** 알람이 울리면 베드사이드 스피커 독에서 알람 버튼을 눌러 알람을 끕 니다.

**알람 스누즈:** 스누즈 버튼 또는 알람을 제외 한 다른 버튼을 눌러 5분 동안 알람을 스누 즈합니다.



디스플레이 밝기: 베드사이드 스피커 독 상 단의 밝기 조정 버튼을 눌러 네 가지 수준의 디스플레이 밝기를 순환합니다.




# 4오디오 소스 연결



베드사이드 스피커 독에 iPod, iPhone, iPod Touch, iPod Nano 또는 iPad를 연결합니다. AC전원에베드사이드스피커독을연결한경 우도킹된 상태에서 장치가 충전됩니다.

# **5** 3.5mm 보조 입력 단자에 오디오 장치 연결\*



\*3.5mm 오디오 케이블은 제공되지 않습니다.

#### 6음악 재생

- 1. 전원 버튼을 눌러 베드사이드스피커 독을 켭니다.
- 2. 사용 가능한 소스로 순환되는 소스 버튼을 사용하여 소스를 선택합니다.
  - 도킹된 장치(예: iPod, iPhone, iPod Touch, iPod Nano 또는 iPad)
  - FM 라디오
  - 보조 장치(예: 베드사이드 스피커 독 후 면의 3.5mm 보조 입력 단자에 연결된 MP3 플레이어 또는 기타 장치)

#### 3. 음악 재생:

- 도킹된 장치 또는 보조 소스의 경우 장 치에서 노래나 음악 트랙을 선택한 다 음 "재생"을 누릅니다. (자세한 내용은 장치 설명서를 참조하십시오.)
- FM 라디오의 경우 튠 + 및 튠 버튼을 사용하여 라디오 채널을 선택합니다. (자세한 내용은 이 안내서의 FM 채널 선택을 참조하십시오.)
- 4. 볼륨 + 및 볼륨 버튼을 사용하여 볼륨 을 조절합니다.

#### **7** FM 채널 선택

베드사이드 스피커 독은 자동 및 수동 FM 튜 닝을 제공합니다.

자동 검색: 오디오 소스로 선택된 FM 라디오에서 튠 + 또는 튠 - 버튼을 길게 눌러 자동 검색을 초기화합니다. 튜닝 가능한 첫 번째 채널을 찾으면 검색이 중지됩니다. 튠 + 또는 튠 - 버튼을 다시 누른 상태로 자동검색을 계속합니다.

수동 검색: 튠 + 또는 튠 - 버튼을 눌러 다음/ 이전 FM 채널을 선택합니다.

#### 문제 해결

#### 베드사이드 스피커 독의 전원이 켜져 있지 않습니다.

- 베드사이드 스피커 독 후면의 전원 입력 단자에 전원 케이블이 연결되어 있습니까?
- 전원 코드가 AC 콘센트에 꽂혀 있습니까?
- 베드사이드스피커 독전원이 켜져 있습니 까? 장치 상단의 전원 버튼을 눌러 베드사 이드 스피커 독을 켭니다.

#### 소리가 나지 않거나 이상하게 변형된 소리 가 납니다.

- 스피커 독에 오디오 장치가 완전히 삽입되 어 있습니까?
- 볼륨을 조절합니다. 볼륨 + 및 볼륨 버튼 을 사용하여 사운드를 조절합니다. 또한 소스 장치에서 볼륨 수준을 확인합니다.
- 3.5mm 보조 입력 단자를 포함한 소스 연결 을 확인합니다.
- 재생하려는 소스를 선택했는지 확인합 니다.
- 3.5mm 보조 입력 단자에 연결된 장치에서 음악을 재생하려고 시도하는 경우 소스 버 튼을 사용하여 해당 장치를 선택합니다.
- 다른 장치를 사용하여 베드사이드 스피커 독을 테스트합니다.

#### 베드사이드 스피커 독에 연결되어 있는 동 안 오디오 장치가 충전되지 않습니다.

- 독에 오디오 장치가 완전히 삽입되어 있 습니까?
- AC 전원 케이블이 베드사이드 스피커 독 에 연결되어 있습니까?
- 오디오 장치의 배터리가 완전히 방전된 경 우 오디오 장치의 원래 전원 어댑터를 사 용하여 복구 충전을 수행할 필요가 있을 것입니다. (복구 충전 수행에 대한 자세한 내용은 오디오 장치와 함께 제공되는 설 명서를 참조하십시오.)

#### FM 수신 상태 불량

• FM 안테나를 다른 위치에 놓거나 안테나 를 돌려서 수신 상태를 향상시켜 보십시오.

로지텍 베드사이드 스피커 독에 대한 추가 문의 사항이 있으면 www.logitech.com/ support를 방문하십시오.



www.logitech.com

© 2011 Logitech. All rights reserved. Logitech, the Logitech logo, and other Logitech marks are owned by Logitech and may be registered. Mac, the Mac logo, iPod, iPhone, iPod Touch, iPod Nano, and iPad are trademarks of Apple, Inc., registered in the U.S. and other countries. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

620-003667.003